



Part No. Description

8100100 DRAG KNOB
 8100200 BRAKE SPRING
 8100300 DRAG WASHER
 8100500 CLICK SPRING
 8100600 SPINDLE
 8100700 AXLE
 8100800 HEX NUT
 8100900 BAFFLE PLATE
 8101100 BAFFLE PLATE WASHER
 8101200 SHIM - DRIVE GEAR
 8101400 BAIL SPRING
 8101600 COUNTERWEIGHT SCREW
 8102000 TRIP LEVER
 8102400 SHIM - HEAD TO HOUSING
 8102500 HOUSING
 8102700 LUBE PORT SCREW
 8102800 OSCILLATION GUIDE SCREW
 8102900 OSCILLATION GUIDE
 8103000 OSCILLATION SLIDE
 8103100 PIVOT GEAR
 8103900 SIDE PLATE SCREW
 8104400 HANDLE KNOB SCREW
 8104700 SHIM - PINION GEAR
 8104900 TRIP LEVER SPRING
 8105000 TRIP LEVER SPRING SCREW
 8182700 SPOOL - SHALLOW GRAPHITE
 8213400 WASHER
 8257600 SIDE PLATE SEAL

Part No. Description

8259000 SIDE PLATE
 8259200 ROTATING HEAD
 8259600 PINION GEAR
 8285000 HANDLE KNOB
 8300400 BAIL MOUNT
 8300700 BAIL BUMPER
 8301200 BAIL SCREW - N1
 8306400 BAIL ASSEMBLY KIT
 8338100 LINE GUIDE
 8338200 LINE GUIDE BUSHING
 8338300 LINE GUIDE WASHER
 8338400 BAIL NUT
 8339600 HANDLE
 8341300 BAIL ARM
 8341500 BAIL WIRE
 8344200 TRANSFER GEAR
 8344300 ANTI-REVERSE DOG
 8344400 DRIVE GEAR
 8344600 TRANSFER GEAR SPACER
 8358700 DRAG WASHER
 8358800 FRICTION WASHER
 8358900 SPOOL - DEEP GRAPHITE
 8361600 COUNTERWEIGHT
 8552500 TRIP LEVER SCREW BUSHING
 8552600 TRIP LEVER SCREW
 8569100 TL SCREW & BUSHING
 8575200 BAIL SCREW - N1 & N2
 8575300 BAIL SCREW BUSHING